


Ballast Mounting

Instruction




TRIPSOLAR

www.tripsolar.com

Solar Bracket Solar System Manufacture


Components List:

Front Connecting Ballast



×2

Joint Ballast




×2

Rear Connecting Plate



×2


M8×20



×20


Installation Steps:

Step1. Place the photosensitive surface of the panel upside down on a flat and clean surface. Install the front and rear Ballast into the holes on the panel and tighten them with screws.



Installation Steps:

Step2. Adjust the direction of the front and rear ballast so that they are in the same straight line, and connect the front and rear ballast with a screw combination and a Joint Ballast



Installation Steps:

Step3. Finished

